GREENE COUNTY RESOURCE MANAGEMENT DEPARTMENT

SOIL EVALUATION - SOIL FACTORS	DATE:
LOCATION:	OWNER/CONTRACTOR NAME
SOIL PIT NUMBER:	DEPTH OF PIT:INCHES
SOIL TYPE:	DEVIATIONS:
FACTOR SUITABILI CLASSIFICATI	
I. TOPOGRAPHY AND LANDSCAPE POSITION A. Slope: B. Slope type: Uniform Complex C. Landscape position: III. SOIL DRAINAGE A. Seasonal High Water Table: Yes Perched Apparent No * B. Depth to low chroma mottling V. RESTRICTIVE HORIZON(S) Yes No Depth and thickness	A. Soil Texture Group Above inches Below inches Depth to clayey horizon (>35% clay): Depth and thickness of unsuitable horizon(s): Horizon with >50% rock fragments: Yes No Depth and thickness: B. Soil Structure: Depth and thickness of unsuitable horizon(s): IV. SOIL DEPTH: VI. AVAILABLE SPACE:
S - Suitable PS - Provis	ionally Suitable U - Unsuitable
Abnormally high potential for good to: Rapid permeability Depth to highly permeab	, Sinkhole

COMMENTS:

*** Some factors rated US may be reclassified PS if the required provisions are met.
Form EV02 (1/94) Page 1 of 2

^{*} Include only low chroma colors due to wetness, indicating a water table.

^{**} If fine textured soils are expected to have a percolation rate slower than 120 min./in., they will be placed in the 4b texture group regardless of the perceived type of clay or amount of chert.

PROFILE DESCRIPTION

Locations	Date:
Pit No.# Soil Type:	Description by:
Parent Material: Vegetat	Vegetative Cover:
	23

Horf-	Depth	2	×	*	m	7 -		おおどのおおおおは 日本の日本の日本の日本の日本の日本の日本の日本の日本の日本の日本の日本の日本の日			
E S	ć	Texture (USDA)	Chert	Cherr *7.609	Consistency	Structure	Roots	(pores, notes)	Munsell Notation	Munseil Bescriptive	
								÷			

1 - Descriptions made in accordance with soil survey manual guidelines.

0 - Sample screened

- 2 1-toam, sit-sitt toam, sct-sandy clay toam, ct-clay toam, sict-sitty clay toam, sc-sandy clay, sic-sitty clay, c-clay.
- 3 Use wet conditions. ss-slightly sticky, s-sitcky, vs-very sticky, sp-slightly plastic, p-plastic, vp-very plastic.

4 - Record grade and shape. 1-wesk, 2-moderate, 3-strong; abk-angular blocky, sbk-subangular blocky, gr-granular.

- 5 f-few, e-common, m-meny; f-fine and/or very fine, m-medium, c-course.
- 6 color descriptions made with moist, broken samples.

GREENE COUNTY RESOURCE MANAGEMENT DEPARTMENT

LOW PRESSURE PIPE SYSTEM DESIGN SUMMARY SHEET FORM EV06 PAGE 1 of 5	DATE: BY:
Daily waste flow: Septic tank size: Pumping tank size: Effluent loading rate: Absorption field area:	gallons gallons gallons gallons gal/sq.ft./day sq. ft.
Total length of laterals: Lateral diameter: Number of laterals: Length of each lateral: Supply line length: Supply line diameter: Manifold placement:	feet inches feet feet inches inches
Hole size: * Hole spacing: Number of holes: Pressure head: Flow per hole: Total flow rate:	inches feet feet gpm gpm
Elevation head: Friction head: Pressure head: Total head: Pump requirements:	feet feet feet feet gpm 0 feet
Storage volume in laterals: Storage volume in supply line: Total storage volume: Dosing volume: Dosing depth:	gallons gallons gallons gallons inches
Check valve needed ?	619-Proj Salaronapor

*NOTE: Data on hole size, spacing, pressure head and flow must be listed for each line for systems (such as sloping lots) where these values may be different for each line.

GREENE COUNTY RESOURCE MANAGEMENT DEPARTMENT

LOW PRESSURE PIPE SYSTEM

DESIGN F	orksheet	
FORM EVO	06 1/94	PREPARED BY:
PAGE 2 C	OF 5	DATE:
ABSORPT1	ON AREA	
STEP 1:	CALCULATE DAILY WASTEWATER FLOW	1
>>>>	bedrooms @ 120 gal/day =	gallons per day (gpd)
STEP 2:	DETERMINE LOADING RATE (from Si	te Evaluation Form EV01)
>>>>	Loading rate = gpd per s	q. ft.
STEP 3:	COMPUTE the total area needed fusing the equation: $A = daily$	or the absorption system flow / loading rate
	Absorption area =	
	gpd /gpd / sq.	ft. = square feet
STEP 4:	DETERMINE the total length of d Spacing between the lines must prevent overloading. Divide the obtain the total length of dist	be 5 feet or more to total area by 5 to
	Total length =	
	sq. ft. / feet =	feet
>>>>	Show lateral line layout on sit Length of lateral lines =	e plan. feet
	Number of lateral lines require	d =
SEPTIC T	<u>ank</u>	
Size is	the same as conventional system.	(= gallons)
PUMPING	TANK	
thus the	ing tank shall provide one day of volume shall be at least twice t stewater flow.	emergency storage, he volume of the
	Minimum volume of pumping tank	NA.
	gpd X 2 = gallons.	Use gal. tank.

LOW	PRI	essu	RE	PIPE	SYSTEM
DESI	GN	WOR	KSI	HEET	
DAGE	3	OF	5		

DOSING RA	ATE .	
The best	starting values for calculations are a 5/32 inch meter, 5 feet hole spacing and a 3 ft. pressure head.	
STEP 1:	Calculate the number of holes. Hole diameter: 5/32 inch. Hole spacing (ft.): Number of holes = length of line / hole spacing	5
	=feet / 5 feet per hole	
	=holes per line	
•	Total # holes =holes per line X lines	
	=holes	
STEP 2:	Determine the flow rate per hole from TABLE 4-1.	
STEP 3:	Calculate the total dosing rate.	
>>>>	Flow rate per hole = gpm	
	Flow rate per line	
	=gpm Xholes per line	
	=gpm	
	Total flow rate	
	=gpm Xlines	
	=gpm	
PUMP SELEC	CTION	
STEP 1:	Compute friction head. Use TABLE 4-2 for pipe friction loss	e

•

!

STEP	1:	Compute friction head	. Use TABLE 4-2 for pipe fi	riction loss
>>>>		Friction head = 1.2 X Diameter of supply lin	pipe friction loss ne & header =	_inches
>>>>		Pipe friction loss =	Length of supply line & header	_feet
			Divided by 100 =	
>>>>		•	Times value from TABLE 4-2 =	_feet/100 ft
		=		feet
		Friction head = 1.2 X	friction loss =	feet

LOW PRESSURE PIPE SYSTEM DESIGN WORKSHEET PAGE 4 OF 5

PUNP SEL	ECTION (continued)
STEP 2:	Calculate total head.
>>>>	Total head =elevation (gravity) head = difference in elevation between pump and highest lateral on the manifold
	+ 3.0 pressure head (ft.)
	+friction head (ft.)
	=feet
STEP 3:	Select pump based on calculated flow rate and total head.
(2)	Pump required:gpm atfeet of head
DOSING VO	DEUME
STEP 1:	Calculate the minimum dosing volume. Use TABLE 4-3 to find the volume of the lateral lines.
	Dosing volume = Volume of supply line + 5 times volume of lateral lines
	A. Supply line diameter =inches length =feet
	Volume of supply line =feet / 100
>>>>.	Xvalue from TABLE 4-3
	=gallons
>>>>	B. Lateral line diameter =inchesfeet
	Volume of lateral lines =feet / 100
>>>>	Xvalue from TABLE 4-3
	=gallons
	C. Dosing volume = gallons
	Plus 5 times volume gallons of laterals
	= gallons
STEP 2.	Select the dosing volume.
	* Dosing two to four times per day provides adequate resting time.

LOW PRESSURE PIPE SYSTEM DESIGN WORKSHEET PAGE 5 OF 5

STEP 3.	Compute the depth of effluent to be pumped per dose in order to set pump on and off float switch settings.
	Dosing depth = dosing volume in gallons divided by 7.48 gallons per cubic foot divided by the area of the septic tank in square feet times 12 inches per foot =gallons / 7.48 gallons per cubic ft.
>>>>	divided bysquare feet
	=X 12 = inches
	NOTE: TO BE DETERMINED AFTER TANK SELECTED
CHECK VAL	VE CALCULATION
	* Use check valves ONLY when total storage volume of pipes is greater than 1/4 of the total daily wastewater volume.
STEP 1:	Calculate storage volume.
	Storage volume = volume of supply line + volume of laterals
	"=gallons +gallons
	=gallons
STEP 4:	Compare to 1/4 daily wastewater volume.
	1/4 Daily wastewater volume =gallons
	Compare to storage volume =gallons
-	CHECK VALVE IS / IS NOT REQUIRED